

Product Overview

The 10-5011 is a SOT handsfree harness for Fiat, Alfa Romeo and Chrysler vehicles with the newer style large radio connector.

Please Note

- The hands-free kit must have an iso mute harness



Common locations:

- Behind radio

Tools Required

- Trim panel removal tools
- Screwdriver or socket set
- Cable ties or loom tape
- Handsfree kit with ISO mute harness



Installation Steps

1. Switch off the ignition and remove the key
2. Remove the radio to access the factory radio connector.
3. Remove the radio to access the factory radio connector.
4. Plug the 10-5011 harness between the vehicle connector and the radio.
5. Connect the ISO mute harness from the handsfree kit to the 10-5011 harness.
6. Secure the wiring, making sure it is not trapped, stretched, or near moving parts.
7. Refit the radio and any removed trim.

Testing

- Turn the ignition on making sure the radio powers on
- Pair hands free kit as required
- Make a test call to ensure audio plays through car speakers
- Check the radio mutes during a call

Need Technical Support?

Message our team on Whatsapp: 07770 814 793

Send your questions and photos so we can help you as quickly as possible.



Chat on WhatsApp